



Time of Day
6:44:10 am

HDD
HAMILTON DIGITAL DESIGNS LTD.
BURLINGTON, ONTARIO, CANADA
(905) 332-1884

7	8	9	+
4	5	6	-
1	2	3	CLEAR
HOLD PEN. MEM.	0	ENTER	RECALL

AUTO HORN	MAN HORN
NEW GAME	ABORT FUNCT.
INTER-MISS	SET TIMER
PERIOD	TIME OF DAY
PEN RUN	PEN. HOLD
TIMER RUN	TIMER HOLD

HOME		GUEST
Green Light	SCORE	Red Light
Green Light	SHOTS	Red Light
Green Light	BONUS	Red Light
Green Light	POSSESSION	Red Light
Green Light	TIME OUT	Red Light
Green Light	PENALTY	Red Light

Hamilton Digital Designs Ltd.
905-332-1884

Operating Instructions for Hockey Scoreboard

Set and Run a Game

- 1) Press "NEW GAME"
- 2) Press "CLEAR"
- 3) "TIMER DIRECTION D" will display
"0" will direct timing up "U"
"1" will direct timing down "D"
- 4) "PERIOD #" will show
Select period desired
- 5) Press "ENTER"
- 6) "PERIOD MINS" will show
Select length of period
Press "ENTER"
Select seconds if required
Press "ENTER"
- 8) Press "TIMER RUN" to start the clock
- 9) Press "TIMER HOLD" to stop the clock

Setup a Penalty

- 1) Press the "HOME" or
"GUEST" PENALTY
- 2) Defaults to "Normal Run Penalty"
To select Special penalty press
"HOLD PEN MEM" until desired penalty
displayed.
- 3) Press "ENTER"
- 4) Type in Player Number
- 5) Press Enter
- 6) "PENALTY MINUTES" will display
- 7) Type number of minutes of penalty
- 8) Press "ENTER"
- 9) Type in number of seconds required
- 10) Press "ENTER"

Setup a Score

- 1) Press "HOME" or "GUEST"
score

HSBINST8

Starting another Period

- 1) Press "PERIOD"
- 2) Select period desired
- 3) Press "ENTER"
- 4) Follow Steps 6) thru 9)

Aborting TIME OUT

- 1) Press "TIME OUT"
- 2) Press "CLEAR"
- 3) Press "ENTER"

Run Lamp Test

- 1) Press "NEW GAME"
- 2) Press "RECALL"
- 3) Press any key to escape

Reset Timer (GAME TIME)

- 1) Press blue "SET TIMER"
button
- 2) If minutes are to be
changed type in new
- 3) If minutes are not changed
press "ENTER"
- 4) Seconds are now displayed
Follow steps 1 to 3
- 5) Press "ENTER" to return to
game mode

Reset Score

- 1) Press "RECALL"
- 2) Press "HOME" or "GUEST" SCORE
- 3) Press "CLEAR"
- 4) Enter new score
- 5) Press "ENTER" to return
to game mode

THIS IS IMPORTANT! ★
Make Sure Auto Horn is set
at "0" for Buzzer to work.

TO START GAME

- #1 Press - New Game
- #2 Press - Clear
- #3 Press - 1 Down
- #4 Press - Period 1
- #5 Press - Minutes in Period
- #6 Press - Enter
- #7 Press - Time Run or Stop

NEW PERIOD

- #1 Press - Period
- #2 Press - # of Period
- #3 Press - Enter
- #4 Press - Minutes in Pe
- #5 Press - Enter
- #6 Press - Run or Stop

PENALTY

- #1 Press - Penalty Home or Visitor
- #2 Press - Enter
- #3 Press - Enter (no # needed) 1, 2, 3, 4, 5, 6, 7, 8, 9,
- #4 Press - Length of Period (example 2 for 2:00 min.)
- #5 Press - Enter
- #6 Press - Enter

TO DELETE A PENALTY

- #1 Press - Penalty - Home or Visitor
- #2 Press - Recall
- #3 Press - Clear
- #4 Press - Enter

Dylan W